

# **DBA SERIES HARDWARE MANUAL**

Rev 5/93

**ELMO-WARRANTY PERFORMANCE**

The warranty performance covers only ELMO's products and only the elimination of problems that are due to manufacturing defects resulting in impaired function, deficient workmanship or defective material. Specifically excluded from warranty is the elimination of problems which are caused by abuse, damage, neglect, overloading, wrong operation, unauthorized manipulations etc.

The following maximum warranty period applies:

<p><b>12 months from the time of operational startup but not later than 18 months from shipment by the manufacturing plant.</b></p>
---

Units repaired under warranty have to be treated as an entity. A breakdown of the repair procedure (for instance of the repair of a unit into repair of cards) is not permissible.


Damage claims, including consequential damages, which exceed the warranty obligation will be rejected in all cases.

If any term or condition in this warranty performance shall be at variance or inconsistent with any provision or condition (whether special or general) contained or referred to in the Terms and Conditions of Sales set out at the back of Elmo's Standard Acknowledge Form, than the later shall prevail and be effective.

## How to use this manual - Flow Chart

The DBA HARDWARE MANUAL will lead you toward a successful start-up of your digital amplifier. Please review carefully the following flow chart and write down the chapters that you have to follow in the right order. Only after performing all the steps you may proceed to the software manual.

If you are a new user of the DBA, you better not skip chapters 1-4 which will familiarize you with the product.



**TABLE OF CONTENTS**

1. Description .....	7
2. Type Designation .....	8
3. Technical Specification .....	9
3.1 Digital I/O specification .....	10
3.2 Analog input specification .....	13
3.3 Sensors specification .....	14
3.3.1 Encoder .....	14
3.3.2 Resolver .....	14
3.4 Communication .....	16
3.4.1 RS232 Configuration .....	16
3.4.2 RS485 Configuration .....	16
3.5 Battery backup .....	16
3.6 Performance .....	16
4. System Operation .....	18
4.1 RS485 and Checksum Protocol .....	18
4.2 Current Control .....	18
4.2.1 Current feedback, Current feedback multiplier (CFM) and Current loop .....	19
4.3 Digital current limits .....	20
4.3.1 Time dependent peak current limit .....	20
4.4 Digital position and speed control .....	21
4.5 Commutation signals format .....	25
4.6 Protective functions .....	26
4.6.1 Short circuit protection .....	26
4.6.2 Under/over voltage protection .....	26
4.6.3 Temperature protection .....	26
4.6.4 Internal power supply failure .....	26
4.6.5 Loss of commutation feedback .....	26
4.6.6 Low back-up Battery voltage .....	26
5. Terminal Description .....	30
5.1 Terminals for Horizontal and Rack mounting versions .....	30
5.2 Mother Boards terminals (MBA-DBA/3U and MBA-DBA/6U) .....	39
5.3 Terminals for DBA mounted in ENCD. ....	49
5.4 Communication Port Connector .....	59
6. Installation procedures .....	60

6.1	Mounting .....	60
6.2	Wiring .....	60
6.3	Load inductance .....	61
6.4	DC power supply .....	61
6.5	Wiring diagrams .....	63
6.5.1	Motor's windings .....	63
6.5.2	AC power wiring .....	64
6.5.3	Hall sensors wiring .....	68
6.5.4	RS232 Communication wiring .....	69
6.5.5	RS485 Communication wiring .....	70
6.5.6	Main encoder wiring .....	72
6.5.7	Resolver wiring .....	73
6.5.8	Auxiliary encoder wiring .....	74
6.5.9	Pulse/Direction signals wiring .....	75
7.	Start - Up Procedures .....	76
7.1	Common procedures for all amplifiers types .....	76
7.1.1	Commutation signals format .....	76
7.1.2	CFM function .....	76
7.1.3	Abort logic .....	76
7.1.4	Setting the auxiliary position input format .....	77
7.1.5	Selecting the communication bus .....	77
7.1.6	Preparing the automatic baud rate selection .....	77
7.2	Setting the main optical encoder format .....	78
7.3	Setting the R/D circuit .....	78
8.	Applying power - Adjustments .....	85
Step 1	- Applying Power .....	85
Step 2	- Establishing the communication .....	86
Step 3	- Checking the feedback elements .....	86
Step 4	- Adjusting the current limits .....	86
Step 5	- Latch mode of the protective functions .....	87
Step 6	- Connecting the Motor .....	87
9.	Tables and Summaries .....	88
9.1	Display diagnostics .....	88
9.2	Summary of DIP switches .....	89
Appendix A	- Current loop response .....	90
Appendix B	- Adding a velocity feedback .....	92

Appendix C - Differential amplifier connection .....93  
List of ELMO Service Centers .....108

## **1. Description**

The DBA series are digital, full wave, three phase servo amplifiers designed for high performance brushless servo motors in the range of up to 8KW. They utilize power MOSFETs and Surface Mounting Technology which contribute to its high efficiency and compact design. The DBA is constructed from two main PCBs mounted on a heat sink plate. The lower board contains the power switching transistors which drive the motor, terminals for the power stage, the switch mode power supply, the protection logic and commutation logic. The upper PCB is the Digital Control Board (DCB) which contains the digital control logic, terminals for the control stage, D-type connector for the communication and a 4-digit display.

The DBA requires a position sensor in order to enable its operation. It can be either a Resolver or a combination of an optical encoder and Hall effect sensors. When using a Resolver, a small interface card is mounted on top of the DCB.

The DBA is available in either panel version or rack version with two DIN 41612 connectors. The rack version can be fitted in a panel mount enclosure (ENCD-3U or ENCD-6U), that is specially designed for a simple hook-up procedure.

The amplifiers are fully protected against the following faults:

- \* Under/over voltage
- \* Shorts between the outputs or between the outputs to ground.
- \* RMS current limit.
- \* Insufficient load inductance.
- \* Loss of commutation signals.
- \* Excess temperature.
- \* Excess position error.


### **Analog Section Standard Features:**

- \* Internal DC/DC converter allows operation from a single supply.
- \* Zero Deadband.
- \* Motor current monitor.
- \* Motor speed monitor.
- \* Extra differential operational amplifier.
- \* Standard commutation sensors: Hall effect sensors or a Resolver.
- \* Galvanic isolation of the control stage - option.

### Digital Section Standard Features

- \* Accepts motion commands via RS232 or RS485
- \* Buffering for pipe lining instructions prior to execution
- \* Battery-backed RAM for storing user programs and parameters
- \* Conditional statements for controlling program execution real- time.
- \* Programmable time and position trip points
- \* Variables for entering and changing system parameters
- \* 5 Uncommitted inputs
- \* 2 uncommitted high speed inputs.
- \* 10 Uncommitted outputs
- \* Arithmetic and logic functions for manipulating parameters
- \* Digital filter with programmable gain, damping and integrator
- \* Error handling, end of travel, emergency stop, status reporting.
- \* 0-600,000 quadrature counts/second speed range
- \* One analog input - 11 bit resolution
- \* Master/slave operation with programmable following ratio (master information from an optical encoder or from Pulse and Direction inputs)
- \* Dual-loop capability
- \* Adjustable continuous and peak current limits
- \* 4-digit display for diagnostics.

### 2. Type Designation





### **3. Technical Specification**

Type	DC Supply	Current limits	Size Panel	Size Rack	Weight (Kg)
DBA-12/75	20-75	2/24	DBA1	3U/13T	0.8
DBA-20/75	20-75	20/40	DBA2	3U/20T	1.5
DBA-12/160	40-160	12/24	DBA2	3U/20T	1.5
DBA-8/330	120-330	8/16	DBA2	3U/20T	1.5
DBA-6/400	200-400	6/12	DBA2	3U/20T	1.5
DBA-30/160	40-160	30/60	DBA3	6U/21T	3.0
DBA-15/330	120-330	15/30	DBA3	6U/21T	3.0
DBA-10/400	200-400	10/20	DBA3	6U/21T	3.0

DBAF-20/75	20-75	20/40	DBA1	3U/13T	0.8
DBAF-10/160	40-160	10/20	DBA1	3U/13T	0.8
DBAF-15/160	40-160	15/30	DBA1	3U/13T	0.8
DBAF-8/330	120-330	8/16	DBA1	3U/13T	0.8
DBAF-10/330	120-330	10/20	DBA2	3U/20T	1.5
DBAF-12/330	120-330	12/24	DBA2	3U/20T	1.5
DBAF-6/400	200-400	6/12	DBA1	3U/13T	0.8
DBAF-8/400	200-400	8/16	DBA2	3U/20T	1.5
DBAF-10/400	200-400	10/20	DBA2	3U/20T	1.5
DBAF-30/160	40-160	30/60	DBA4	6U/14T	1.8
DBAF-15/330	120-330	15/30	DBA4	6U/14T	1.8
DBAF-20/330	120-330	20/40	DBA4	6U/14T	1.8
DBAF-25/330	120-330	25/50	DBA5	6U/21T	3.5
DBAF-12/400	200-400	12/24	DBA4	6U/14T	1.8
DBAF-25/400	200-400	25/50	DBA5	6U/21T	3.5

**General**

- \* Maximum DC output voltage is 90% of DC input voltage.
- \* 2KHz current loop response
- \* Outputs voltages of +5V/0.2A, +15V/0.1A for external use.
- \* Efficiency at rated current - 97%.
- \* Operating temperature: 0 - 40°C.
- \* Storage temperature: -10 - +60°C.

**3.1 Digital I/O specification****Digital Inputs:**

High/Low input definition:  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$

Maximum input voltage: 30V

Input impedance: 3-7Kohm

Input hysteresis: typ 1V.

When left open: low level.

Input threshold level can be shifted on request.

The fast inputs capture events (input voltage level going from low to high) of less than 10µsec duration.

**Digital Outputs:**





High/Low output definition:  $V_{ol} < 0.4V$ ,  $V_{oh} > 4V$

Output level: 0-5V


Recommended output current:  $I_{ol} = I_{oh} = 5mA$

Maximum output current +10mA

The outputs are normally at low level.



## DIGITAL OUTPUTS



## DIGITAL INPUTS


### 3.2 Analog input specification

Maximum input voltage:

- When R1 (470ohm) is inserted, the absolute value of the input voltage should be less than 5V.
  - When the absolute value is higher than 5V,  $R1(Kohm) = 2Vi - 10$  should be inserted.
- The  $\mu P$  reads always  $\pm 5V$ .

Resolution of the digital conversion: 11 bit full scale.

Typical offset: 5 bits



### 3.3 Sensors specification

#### 3.3.1 Encoder

The encoder must be incremental with two TTL channels in quadrature and 90° phase shift.

High/Low input definition:  $V_{il} < 1.5V$ ,  $V_{ih} > 3V$

Input voltage range: 0-15V

Input hysteresis 1.5V

Input impedance: 1Kohm to 5V.

Maximum frequency main encoder: 150KHz

Maximum frequency auxiliary encoder: 250KHz

Noise protection by analog and digital filters

When left open the input is internally pulled to high level.

#### 3.3.2 Resolver

##### **Resolver Option Feature:**

- \* 10,12,14 and 16 bit resolution set by the user.
- \* Maximum tracking rate 1040 rps (10 bits).
- \* Velocity output.
- \* Encoder A, B, outputs + programmable index output.


##### **Reference parameters:**

Max. voltage: 20V<sub>ptp</sub> or 7V<sub>rms</sub>

Minimum output voltage: 2V<sub>rms</sub>

Max. current: 80mA

Max frequency: 20KHz outputs:



## 3.4 Communication

### 3.4.1 RS232 Configuration

The RS232 is configured for 8-bit, no parity, full duplex and it will echo all the transmissions.

Baud rates: 300,600,1200,2400,4800,9600,19200,38400,57600

No hardware handshaking is required.

### 3.4.2 RS485 Configuration

The RS485 is configured for 8-bit, no parity, half duplex.

Baud rates: 300,600,1200,2400,4800,9600,19200,38400,57600

No hardware handshaking is required.

## 3.5 Battery backup

180mAH battery that at rated operating and storage condition will last for at least 40,000 non operating hours.

## 3.6 Performance

Position range:  $\pm 2^{30}$  quadrature counts


Velocity range:  $\pm 600,000$  counts/sec

Velocity resolution: 1 count/s

Acceleration range: 91 -  $11.8 \times 10^6$  count/s

Acceleration resolution: 91 counts/s<sup>2</sup>





## **4. System Operation**

### **4.1 RS485 and Checksum Protocol**

The RS485 in the DCB is configured as 8-bit, no parity, 1 stop bit, half duplex. The following baud rates are available: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600. No hardware handshaking is required.

In the RS-485, which is a Half Duplex system, all the Transmitters and all the Receivers share the same Multidrop wire. Therefore, each character that is transmitted on the line, is automatically received by all the Receivers. This is an inherently "confused" way to transmit data and no "Echo" procedure can assure reliable communication.

In order to solve this reliability problem, it is necessary to use standard protocols procedures.

It is important to understand that using RS485 with the DCB products without any protocol is possible. This is also the default condition whenever the RS485 is activated. However, the reliability of the communication is only assured when activating the protocol. This is done by sending the command CK1 from the host to the DCB.

Chapter 1.2.1 in the DCB Software manual explains the standard protocol used and supplied by Elmo.

### **4.2 Current Control**


The analog part of the DBA is actually a standard amplifier that operates in current mode. However, the DCB receives continuously analog information about the current magnitude, direction and ripple. This information is processed to obtain digital control of the following features:

- \* Continuous current limit
- \* Peak current limit
- \* Time dependent peak current limit
- \* Current ripple

#### 4.2.1 Current feedback, Current feedback multiplier (CFM) and Current loop

Three current feedbacks are obtained by measuring the voltage drop across current sensing resistors or by current transformers (when using the isolation option). These three signals are synthesized and multiplexed which result in a single voltage signal proportional to phases currents. It is then compared to the current command. The error is processed by the current amplifier to provide a voltage command to the PWM section.

Current loop control is obtained by op amp U21/A (current amplifier) and R4, C1 which form a lag-lead network for current loop. The standard amp is equipped with R4 and C1 to get optimum current response for an average motor in this power range. These components are mounted in solderless terminals.



The amplifier is equipped with a Current Feedback Multiplier (CFM). By turning DIP switch 2 (on the upper board of the power stage) to ON, the signal of the current feedback is multiplied by 2 and consequently the following changes occur:

- Current gains are multiplied by 2.
- Current monitor is divided by 2.
- Current limits are divided by 2.
- Dynamic range is improved.
- Commutation ripple is reduced.

This function should be activated whenever the rated current AND the peak current of the motor are less than 20% of the amplifier rated continuous and peak limits respectively.

Sometimes, oscillations may occur in the current loop due to the fact that the feedback gain was multiplied. This can be resolved by substituting R4 with a lower value.

### 4.3 Digital current limits

The servo amplifier can operate in the following voltage-current plane:

		+V	
-Ip	-Ic	Ic	Ip
Intermittent zone	Continuous zone	-V	

Ic - Continuous current

Ip - Peak current

Fig. 4.1: Voltage-Current plane

Each amplifier is factory adjusted to have this shape of voltage-current operating area with rated values of continuous and peak current limits. By using the command CL(n) for the continuous and PL(n) for the peak it is possible to adjust the current limits (continuous and peak independently) from the rated values down to 10% of the rated values.

#### 4.3.1 Time dependent peak current limit

The peak current duration is a programmable parameter which is also a function of the peak amplitude and the motor operating current before the peak demand. The user defines the maximum duration of the full amplitude peak by the instruction PDn - n cannot be more than 2 seconds. In addition to this definition, a digital filter is employed to ensure that the RMS value of the current will not exceed the continuous current limit. The duration of Ip is given by:

$$T_p = 2.2 \ln \frac{I_p - I_{op}}{I_p - I_c}$$

$I_{op}$  - Actual operating current before the peak demand.

The result of this filter is that the maximum peak can last for a maximum of 2 seconds. A lower peak can last longer.

Example: A motor is driven by an DBAF-10/160 amplifier at constant speed and constant current of 5A. What is the maximum possible duration of a 20A peak ?

$$T_p = 2.2 \ln \frac{20 - 5}{20 - 10} = 0.892 \text{ seconds}$$

#### 4.4 Digital position and speed control

The DCB accepts motion commands via an RS232 or RS485 communication line and receives position feedback in an incremental encoder format either from an encoder or from the resolver/digital circuit. The DCB derives the closed-loop position error by comparing the command position and the feedback position. The error is processed by a digital filter to yield with an analog motor command. The analog  $\pm 5$  volt range motor command is then amplified by the power amplifier.

Following is a summary of all the operating modes of the DCB and a detailed discussion of each of them.

**Control Modes**

**Holding Modes.**

**Start Modes**

**Program Mode**

**Termination Modes**

**Status reporting**

**Define origin modes**

## **Control Modes**

The DCB can be commanded to control the position of a motor, its torque or its velocity using three basic control modes:

- Position Mode
- Velocity Mode
- Position Follower Mode

### **Position Mode**

In the position mode the motor will advance a specified distance and then stop. This distance can be represented as an absolute position (PA n) or as a relative distance from the current position (PR n). The motion will follow a trapezoidal or triangular profile with the acceleration (AC n) and slew velocity (SP n) set by the user.

### **Velocity Mode**

In the velocity mode the motor will accelerate to a specified slew speed. It will hold this speed until a stop condition is received (see termination modes), or a new velocity/direction is commanded.

### **Position Follower**

It can also control the motor as a position follower of a master encoder or a pulse and direction signals.

## **Holding Modes.**

The holding modes describe the behavior of the system after it has stopped. There are three holding modes:

- Servo
- Motor Off

### **Servo Mode**

In the servo mode (SV) the system maintains stopping position by using its control law to correct for any position errors.

### **Motor Off Mode**

In the Motor Off mode is, the power bridge and the position control are shut off and there no torque is generated by the amplifier. The Motor Off mode is useful in robotics applications in the teaching mode.

## **Start Modes**

There are three start modes to begin a move:

### **Direct command**

A move can be initiated directly by a command from the host or a terminal.

### **Program**

A move can be initiated by a command included in the user program.

### **Input condition**

Another alternative is to have the move started by a conditional statement specified by the user program.

## **Program Mode**

A set of commands can be implemented as a user program to allow for automatic and/or complex types of moves. The user may specify software variables, conditional statements, subroutines and error routines which enable enhanced motion control.

## **Termination Modes**

A motion can be terminated in a variety of ways. In all but emergency termination modes the motor will be decelerated gradually to a stop and then will enter one of the stationary modes (Servo, Deadband, or Motor Off). In a position mode move, the motion will terminate naturally upon reaching the desired final position. In all of the control modes the motion can be terminated by a command from the host. An additional means of termination is from one of the local inputs.

Activating the forward and reverse limit switch inputs can be another means of terminating a move. Upon contacting the switch, the #[] routine will be activated. This is a user programmed routine that should normally include a stop command to decelerate the motor to a full stop.

There are two methods of generating an emergency stop. The first is by an abort command from the host, and the other is by the local abort input. Upon receipt of either of these commands the system will go immediately to its stationary mode.

Another "unnatural" way to terminate a motion is whenever an internal amplifier inhibit (due to one of the protections) occurs. This turns off the power stage and the motor will decelerate to a stop by friction only. There are two modes of handling the internal amplifier inhibit:

### **Latch Mode**

The power stage is disabled and only a reset will release it.

**Auto restart**

The power stage inhibit will automatically be released upon clearing the cause of the inhibit.

**Status Reporting**

Status is available to the user in several ways.

**Communication**

In response to the Tell Status command (TS) the DCB sends a coded message describing the status of the amplifier.

In addition, the host may request certain information at any time. This consists of the state of the system (GN?, ZR?, PL?, KI?), the state of the local inputs (TI), the torque level (TT), the current motor position (TP), the current motor velocity (TV) and the reason for a stop condition (TC).

Refer to the DCB Software Manual for further details.

**Hardware signal****Motion complete signal**

This output will go to high when motion is complete.

**Inhibit output**

Whenever the amplifier is inhibited, this open collector output goes to low. When using Elmo's mother boards a potential free relay replaces the open collector output.

**4-digit display**


Whenever a fault occurs, a fault message will be displayed for easy visual information. See chapter 9.1 for a summary of all amplifier's fault indications.

**Define origin modes**

The origin is that location at which the absolute position of the motor equals zero. This special location may be defined in two ways. First, the user may send a command (DH) which defines the current motor position to be the origin. The alternate method is to request the DCB to perform the homing sequence by commanding HM.



### 4.5 Commutation signals format



## **4.6 Protective functions**

All the protective functions except "Low Back-up Battery Voltage" activate an interrupt to the main processor which inhibits the power bridge and disable current flow to or from the motor. The user can interrogate the processor in order to verify the cause of the inhibit. An indication of the fault will appear on the display. The following protections are processed by the DCB:

### **4.6.1 Short circuit protection**

The amplifier is protected against shorts between outputs, or either output to ground, or either output to the positive supply line.

### **4.6.2 Under/over voltage protection**

Whenever the DC bus voltage is under or over the limits indicated in the technical specifications, the amplifier will be inhibited.

### **4.6.3 Temperature protection**

Temperature sensor is mounted on the heatsink. If, for any reason, the temperature exceeds 85°C the amplifier will be inhibited. The amplifier will restart when the temperature drops below 80°C. The user can always interrogate the DCB about the heatsink temperature by using the command T?.

### **4.6.4 Internal power supply failure**


In any case that the sum of the internal power supplies is below 13V or its difference higher than 1V, the amplifier will be inhibited.


### **4.6.5 Loss of commutation feedback**

Lack of either of the commutation signals will inhibit the amplifier.


### **4.6.6 Low back-up Battery voltage**

When the battery voltage goes below 2.4V the DCB will send a message on the communication line and will display "BATT" on the display.





# DCB COMPONENTS LAYOUT



## 5. Terminal Description

### 5.1 Terminals for Horizontal and Rack mounting versions

POWER BOARD - 3U si

H	R	Function
1	(30,32)	Power input common. In the DIN connector all four pins must be connected.
2	(26,28)	Motor phase A output. In the DIN connector all four pins must be connected.
3	(22,24)	Motor phase B output. In the DIN connector all four pins must be connected.
4	(18,20)	Motor phase C output. In the DIN connector both pins must be connected.
5	(14,16)	(+Vs) Power input positive. In the DIN connector all pins must be connected.
6	(12c)	Hall sensor A *
7	(10c)	Hall sensor B *
8	(8c)	Hall sensor C *
9	(6c)	Not connected
10	(4c)	24VDC Fan common (shorted to control common)
11	(2c)	24VDC Fan supply (up to 0.4A)

Power Board - 6U size - Power connector

H	R	Function
1	(28,30,32)	Power input common. In the DIN connector all three pins must be connected.
2	(22,24,26)	Motor phase A output. In the DIN connector all three pins must be connected.
3	(16,18,20)	Motor phase B output. In the DIN connector all three pins must be connected.

\*  $-1V \leq V_{il} \leq 1V$  ;  $2V \leq V_{ih} \leq 30V$

Source sink capability - 2mA min.

## Power Board - 6U size - Power connector, cont.

H	R	Function
4	(10,12,14)	Motor phase C output. In the DIN connector all three pins must be connected.
5	(4,6,8)	(+Vs) Power input positive. In the DIN connector all three pins must be connected.

## Power Board - 6U size - Signals connector

H	R	Function
6	(32c)	Hall sensor A *
7	(30c)	Hall sensor B *
8	(28c)	Hall sensor C *
12	(20c)	Circuit common for +15V supply
13	(18c)	+15V supply, 100mA.
14	(16c)	24VDC common - fan only.
15	(14c)	+24VDC isolated supply for fan (max. 400mA)

**Control board**

H & R	Function	Remarks
1a	Output 6	**
1b	Current monitor	This analog output represents the actual current in the motor. The scale (in A/V) is: $I_p / 7.5$ $I_p$ - Rated peak current of amplifier.
2a	Output 7	**
2b	Velocity / current mode selection	When input is left open (low level) the analog part of the amplifier is working in current mode. when a high level signal is applied (>2V), the analog part of the amplifier is working as a high gain velocity amplifier.***
3a	Output 8	**

\*  $-1V \leq V_{il} < 1V$  ;  $2V \leq V_{ih} < 30V$

Source sink capability - 2mA min.

\*\*  $V_{ol} < 0.4V$ ,  $V_{oh} > 4V$ , Output level: 0-5V, max output current  $\pm 5mA$

\*\*\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage:  $\pm 30VDC$

## Control board - cont.

H & R	Function	Remarks
3b	Motion command ( <u>+5V</u> )	This analog output represents the current command from the position loop to the power amplifier. It is useful for monitoring the position loop response.
4a	Circuit common	
4b	Circuit common	
5a	Fast output 9	*
5b	+5V output	There are several +5V terminals. The accumulative external load should not exceed 200mA.
6a	Fast output 10	*
6b	Circuit common	
7a	Motion Complete	This output will go to high when motion is complete. *
7b	+15V output	100mA.
8a	Inhibit output	Whenever the amplifier is inhibited, this open collector output goes low.
8b	-15V output	100mA.
9a	Forward limit switch	This committed input activates the #[ subroutine. **
9b	positive input of a differential amplifier.	See Appendix C.
10a	Reverse limit switch	This committed input activates the #[ subroutine. **
10b	Negative input of a differential amplifier.	See Appendix C.
11a	Circuit common	

---

\* Vol<0.4V, Voh>4V, Output level: 0-5V, max output current +5mA

\*\* Vil<1V, Vih>2.4V, Maximum input voltage: +30VDC



## Control board - cont.

H & R	Function	Remarks
11b	Output of a differential amplifier.	See Appendix C.
12a	Home switch	*
12b	Tachogenerator output/input	When using the resolver option this output is the velocity monitor with a scale of 8V for maximum speed. See 7.3.
13a	Abort input	This input must be connected to high level voltage to enable the amplifier.*
13b	Output 1	**
14a	Circuit common	
14b	Output 2	**
15a	Fast input 6	This fast response input can capture events with a duration of less than 10 $\mu$ s. An event is defined as an input voltage transition from low to high. *
15b	Output 3	**
16a	Fast input 7	Same function as Fast Input 6 (15a). *
16b	Output 4	**
17a	Reset input	*
17b	Output 5	**
18a	Analog input	This input is monitored by the main $\mu$ P. When $ V_i  \leq 5V$ , $R_1=470\text{ohm}$ should be inserted. When $ V_i  > 5V$ , $R_1(\text{Kohm})=2V_i-10$ should be inserted. The $\mu$ P always reads a range of <u>+5V</u> .
18b	Input 1	*
19a	+5V output	There are several +5V terminals. The accumulative external load should not exceed 200mA.
19b	Input 2	*
20a	Circuit common	

---

\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage:  $\pm 30VDC$

\*\*  $V_{ol} < 0.4V$ ,  $V_{oh} > 4V$ , Output level: 0-5V, max output current  $\pm 5mA$

## Control board - cont.

H & R	Function	Remarks
20b	Input 3	*
21a	Auxiliary encoder input (Ay) or pulse input for Pulse and Direction mode.	
21b	Input 4	*
22a	Auxiliary encoder complementary input (-Ay) or complementary Pulse and Direction mode	
22b	Input 5 or Index Input.	If a homing sequence is required, the Index Input must be connected to Input 5 *
23a	Auxiliary encoder input (By) or Direction input for Pulse and Direction mode	
23b	Resolver reference	Max. voltage: 20Vptp or 7Vrms Max current: 80mA Max frequency: 20KHz

---


\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage: +30VDC

## Control board - cont.

H & R	Function	Remarks
24a	Auxiliary encoder complementary input (-By) or Complementary Direction input for Pulse and Direction mode	
24b	Resolver reference common.	The reference voltage to the resolver must be taken from terminals 23b and 24b only.
25a	+5V output	There are several +5V terminals. The accumulative external load should not exceed 200mA.
25b	Cosine signal input.	See 7.3
26a	Circuit common	For the auxiliary encoder
26b	Cosine signal common.	See 7.3
27a	Channel B input	
27b	Sine signal input.	See 7.3
28a	Channel -B input	
28b	Sine signal common	See 7.3
29a	Channel A input	
29b	Circuit common	For the main encoder
30a	Channel -A input	
30b	Index output	For resolver option only.
31a	-Index input	
31b	Channel B output	
32a	Index input	
32b	Channel A output	


Remark: In the following paragraphs the terminals will be related to all the mounting types as in the following sample:

H/R-2a,E-J4/13.



# TERMINALS LAYOUT


## CONTROL BOARD



DBA - PANEL (H) MOUNTING TYPE

EUROCARD SIZE TYPES

# TERMINALS LAYOUT



DBA - PANEL (H) MOUNTING TYPE  
DOUBLE EUROCARD SIZE TYPES

## 5.2 Mother Boards terminals (MBA-DBA/3U and MBA-DBA/6U)

Use: For all DBA amplifiers (3U/6U size) with Resolver or optical encoder feedback. The encoder outputs are driven by line drivers to improve noise immunity.

Termination: Screw type terminals for the power and D-type connectors for the signals.

### POWER TERMINALS FOR MBA-DBA/

Terminal	Function
1	Power input common.
2	Motor phase A output.
3	Motor phase B output.
4	Motor phase C output.
5	(+Vs) Power input positive.
10	24VDC Fan common (shorted to control common)
11	24VDC Fan supply (up to 0.4A)

### POWER TERMINALS FOR MBA-DBA/6U

Terminal	Function
1	Power input common.
2	Motor phase A output.
3	Motor phase B output.
4	Motor phase C output.
5	(+Vs) Power input positive.

**Signals connector - J1 (MBA-DBA/3U and MBA-DBA/6U)**

Pin	Function	Remarks
1	Channel A input	
2	Channel -A input	
3	Channel B input	
4	Channel -B input	
5	-Index input	
6	Index input	
7	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
8	+15V output	There are several +15V pins. The accumulative external load should not exceed 100mA.
9	Circuit common	

**Signals connector - J2 (MBA-DBA/3U and MBA-DBA/6U)**

Pin	Function	Remarks
1	Resolver reference	Max. voltage: 20Vptp or 7Vrms Max current: 80mA Max frequency: 20KHz
2	Resolver reference common.	The reference voltage to the resolver must be taken from pins 1 and 2 only.
3	Cosine signal input.	See 7.3
4	Cosine signal common.	See 7.3
5	Sine signal input.	See 7.3
6	Sine signal common	See 7.3
7	+15V output	There are several +15V pins. The accumulative external load should not exceed 100mA.
8	-15V output	There are several -15V pins. The accumulative external load should not exceed 100mA.
9	Circuit common	



**Signals connector - J3 (MBA-DBA/3U and MBA-DBA/6U)**

Pin	Function	Remarks
1	positive input of a differential amplifier.	See Appendix C.
2	Negative input of a differential amplifier.	See Appendix C.
3	Output of a differential amplifier.	See Appendix C.
4	Circuit common	
5	Analog input	This input is monitored by the main $\mu$ P. When $ V_i  \leq 5V$ , $R1=470ohm$ should be inserted. When $ V_i  > 5V$ , $R1(Kohm)=2V_i-10$ should be inserted. The $\mu$ P always reads a range of <u>+5V</u> .
6	Circuit common	
7	Circuit common	
8	Current monitor	This analog output represents the actual current in the motor. The scale (in A/V) is: $I_p / 7.5$ $I_p$ - Rated peak current of amplifier.
9	Circuit common	
10	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
11	+15V output	There are several +15V pins. The accumulative external load should not exceed 100mA.
12	-15V output	There are several -15V pins. The accumulative external load should not exceed 100mA.
13	Channel B output	
14	Channel A output	
15	Index output	For resolver option only.
16	Not connected	
17	Inhibit output	Relay contact (potential free). The relay contact is closed whenever the amplifier is enabled. Contact rating: 0.5A, 200V, 10W.

## Signals connector - J3 - cont.

Pin	Function	Remarks
18	Inhibit output	Relay contact (potential free). The relay contact is closed whenever the amplifier is enabled. Contact rating: 0.5A, 200V, 10W.
19	Motion command ( <u>±</u> 5V)	This analog output represents the current command from the position loop to the power amplifier. It is useful for monitoring the position loop response.
20	Circuit common	
21	Reset input	*
22	Circuit common	
23	Tachogenerator output/input	When using the resolver option this output is the velocity monitor with a scale of 8V for maximum speed. See 7.3.
24	Circuit common	
25	Velocity / current mode selection	When input is left open (low level) the analog part of the amplifier is working in current mode. when a high level signal is applied (>2V), the analog part of the amplifier is working as a high gain velocity amplifier. *
26	Not connected	

## Signals connector - J4 (MBA-DBA/3U and MBA-DBA/6U)

Pin	Function	Remarks
1	Input 1	*
2	Input 2	*
3	Circuit common	
4	Input 3	*
5	Input 4	*

---

\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage: ±30VDC

## Signals connector - J4 - cont.

Pin	Function	Remarks
6	Input 5 or Index Input.	If a homing sequence is required, the Index Input must be connected to Input 5.
7	Circuit common	
8	Fast input 6	This fast response input can capture events with a duration of less than 10 $\mu$ s. An event is defined as an input voltage transition from low to high. *
9	Fast input 7	Same function as Fast Input 6 (8).
10	Circuit common	
11	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
12	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
13	Output 7	**
14	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
15	Output 1	**
16	Output 2	**
17	Output 3	**
18	Circuit common	
19	Output 4	**
20	Output 5	**
21	Output 6	**
22	Circuit common in 3U types or Output 8 in 6U types	
23	Output 9	**

---

\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage:  $\pm 30VDC$

\*\*  $V_{ol} < 0.4V$ ,  $V_{oh} > 4V$ , Output level: 0-5V, max output current  $\pm 5mA$

## Signals connector - J4 - cont.

Pin	Function	Remarks
24	Output 10	*
25	Motion Complete	This output will go to high when motion is complete. *
26	Output 8 in 3U types only.	*

## Signals connector - J6 (MBA-DBA/3U and MBA-DBA/6U)

Pin	Function	Remarks
1	Auxiliary encoder complementary input (-By) or Complementary Direction input for Pulse and Direction mode	
2	Auxiliary encoder input (By) or Direction input for Pulse and Direction mode	
3	Auxiliary encoder input (Ay) or pulse input for Pulse and Direction mode.	
4	Auxiliary encoder complementary input (-Ay) or complementary Pulse and Direction mode	

---

\* Vol<0.4V, Voh>4V, Output level: 0-5V, max output current +5mA

## Signals connector - J6 - cont.

Pin	Function	Remarks
5	Auxiliary encoder index input	
6	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
7	+15V output	There are several +15V pins. The accumulative external load should not exceed 100mA.
8	Circuit common	
9	Home switch	*
10	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
11	Abort input	This input must be connected to high level voltage to enable the amplifier. *
12	+5V output	200mA
13	Forward limit switch	This committed input activates the #[] subroutine. *
14	Reverse limit switch	This committed input activates the #[] subroutine. *
15	Circuit common	

**J1A, FAN TERMINALS - (MBA-DBA/6U ONLY)**

10	24VDC common - fan only.
11	+24VDC isolated supply for fan (max. 400mA)

---

\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage:  $\pm 30VDC$

**Signals connector - J8 (MBA-DBA/3U and MBA-DBA/6U)**


1	Channel A output	Main encoder buffered output (20mA, 0-5V)
2	Channel -A output	Main encoder buffered output (20mA, 0-5V)
3	Channel B output	Main encoder buffered output (20mA, 0-5V)
4	Channel -B output	Main encoder buffered output (20mA, 0-5V)
5	Encoder index output	For resolver option only buffered output (20mA, 0-5V)
6	Encoder -index output	For resolver option only buffered output (20mA, 0-5V)
7	Circuit common	
8	Circuit common	
9	Circuit common	
10	Hall A	*
11	Hall B	*
12	Hall C	*
13	+15V	There are several +15V pins. The accumulative external load should not exceed 100mA.
14	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
15	Circuit common	

Remark: In the following paragraphs the terminals will be related to all the mounting types as in the following sample:


H/R-2a,E-J4/13.

---

\*  $-1V \leq V_{il} < 1V$  ;  $2V \leq V_{ih} < 30V$   
Source sink capability - 2mA min.



## MBA - DBA/3U





### 5.3 Terminals for DBA mounted in ENCD.

POWER TERMINALS FOR MBA-DBA/3UE and MBA-DBA/6

Terminal	Function
1	Power input common
2	Motor phase A output.
3	Motor phase B output.
4	Motor phase C output
5	Power input positive
G	Ground. This terminal is connected to the ENCD chassis.

#### Attention:

DC power commons, control commons and fan common are floating with respect to each other. Do not short them unless specified.

For isolated amplifiers connecting control common to ground is accomplished by inserting R2 (short resistor) on the mother board.

#### Signals connector - J1 (MBA-DBA/3UE and MBA-DBA/6UE)

Pin	Function	Remarks
1	Channel A input	
2	Channel -A input	
3	Channel B input	
4	Channel -B input	
5	-Index input	
6	Index input	
7	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
8	+15V output	There are several +15V pins. The accumulative external load should not exceed 100mA.
9	Circuit common	

**Signals connector - J2 (MBA-DBA/3UE and MBA-DBA/6UE)**

Pin	Function	Remarks
1	Resolver reference	Max. voltage: 20Vptp or 7Vrms Max current: 80mA Max frequency: 20KHz
2	Resolver reference common.	The reference voltage to the resolver must be taken from pins 1 and 2 only.
3	Cosine signal input.	See 7.3
4	Cosine signal common.	See 7.3
5	Sine signal input.	See 7.3
6	Sine signal common	See 7.3
7	+15V output	There are several +15V pins. The accumulative external load should not exceed 100mA.
8	-15V output	There are several -15V pins. The accumulative external load should not exceed 100mA.
9	Circuit common	

**Signals connector - J3 (MBA-DBA/3UE and MBA-DBA/6UE)**

Pin	Function	Remarks
1	positive input of a differential amplifier.	See Appendix C.
2	Negative input of a differential amplifier.	See Appendix C.
3	Output of a differential amplifier.	See Appendix C.
4	Circuit common	
5	Analog input	This input is monitored by the main $\mu$ P. When $ V_i  \leq 5V$ , $R_1=470\text{ohm}$ should be inserted. When $ V_i  > 5V$ , $R_1(\text{Kohm})=2V_i-10$ should be inserted. The $\mu$ P always reads a range of +5V.

## Signals connector - J3 - cont.

Pin	Function	Remarks
6	Circuit common	
7	Circuit common	
8	Current monitor	This analog output represents the actual current in the motor. The scale (in A/V) is: $I_p / 7.5$ $I_p$ - Rated peak current of amplifier.
9	Circuit common	
10	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
11	+15V output	There are several +15V pins. The accumulative external load should not exceed 100mA.
12	-15V output	There are several -15V pins. The accumulative external load should not exceed 100mA.
13	Channel B output	
14	Channel A output	
15	Index output	For resolver option only.
16	Not connected	
17	Inhibit output	Relay contact (potential free). The relay contact is closed whenever the amplifier is enabled. Contact rating: 0.5A, 200V, 10W.
18	Inhibit output	Relay contact (potential free). The relay contact is closed whenever the amplifier is enabled. Contact rating: 0.5A, 200V, 10W.
19	Motion command ( <u>+5V</u> )	This analog output represents the current command from the position loop to the power amplifier. It is useful for monitoring the position loop response.
20	Circuit common	
21	Reset input	*
22	Circuit common	

\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage: +30VDC

## Signals connector - J3 - cont.

Pin	Function	Remarks
23	Tachogenerator output/input	When using the resolver option this output is the velocity monitor with a scale of 8V for maximum speed. See 7.3.
24	Circuit common	
25	Velocity / current mode selection	When input is left open (low level) the analog part of the amplifier is working in current mode. when a high level signal is applied (>2V), the analog part of the amplifier is working as a high gain velocity amplifier. *

## Signals connector - J4 (MBA-DBA/3UE and MBA-DBA/6UE)

1	Input 1	*
2	Input 2	*
3	Circuit common	
4	Input 3	*
5	Input 4	*
6	Input 5 or Index Input.	If a homing sequence is required, the Index Input must be connected to Input 5.
7	Circuit common	
8	Fast input 6	This fast response input can capture events with a duration of less than 10 $\mu$ s. An event is defined as an input voltage transition from low to high. *
9	Fast input 7	Same function as Fast Input 6 (8).

---

\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage:  $\pm 30VDC$

## Signals connector - J4 - cont.

Pin	Function	Remarks
10	Circuit common	
11	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
12	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
13	Output 7	*
14	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
15	Output 1	*
16	Output 2	*
17	Output 3	*
18	Circuit common	
19	Output 4	*
20	Output 5	*
21	Output 6	*
22	Circuit common in 3U types or Output 8 in 6U types	
23	Output 9	*
24	Output 10	*
25	Motion Complete	This output will go to high when motion is complete. *

---

\*  $V_{ol} < 0.4V$ ,  $V_{oh} > 4V$ , Output level: 0-5V, max output current  $\pm 5mA$

## Signals connector - J6 (MBA-DBA/3UE and MBA-DBA/6UE)

Pin	Function	Remarks
1	Auxiliary encoder complementary input (-By) or Complementary Direction input for Pulse and Direction mode	
2	Auxiliary encoder input (By) or Direction input for Pulse and Direction mode	
3	Auxiliary encoder input (Ay) or pulse input for Pulse and Direction mode.	
4	Auxiliary encoder complementary input (-Ay) or complementary Pulse and Direction mode	
5	Auxiliary encoder index input	
6	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
7	+15V output	There are several +15V pins. The accumulative external load should not exceed 100mA.
8	Circuit common	
9	Home switch	*
10	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
11	Abort input	This input must be connected to high level voltage to enable the amplifier. *

\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage:  $\pm 30VDC$

## Signals connector - J6 - cont.

Pin	Function	Remarks
12	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
13	Forward limit switch	This committed input activates the #[] subroutine. *
14	Reverse limit switch	This committed input activates the #[] subroutine. *
15	Circuit common	

## Signals connector - "FAN" (MBA-DBA/6UE ONLY)

10	24VDC common - fan only.
11	+24VDC isolated supply for fan (max. 400mA)

---

\*  $V_{il} < 1V$ ,  $V_{ih} > 2.4V$ , Maximum input voltage:  $\pm 30VDC$

**Signals connector - J8 (MBA-DBA/3UE and MBA-DBA/6UE)**

Pin	Function	Remarks
1	Channel A output	Main encoder buffered output (20mA, 0-5V)
2	Channel -A output	Main encoder buffered output (20mA, 0-5V)
3	Channel B output	Main encoder buffered output (20mA, 0-5V)
4	Channel -B output	Main encoder buffered output (20mA, 0-5V)
5	Encoder index output	For resolver option only buffered output (20mA, 0-5V)
6	Encoder -index output	For resolver option only buffered output (20mA, 0-5V)
7	Circuit common	
8	Circuit common	
9	Circuit common	
10	Hall A	*
11	Hall B	*
12	Hall C	*
13	+15V	There are several +15V pins. The accumulative external load should not exceed 100mA.
14	+5V output	There are several +5V pins. The accumulative external load should not exceed 200mA.
15	Circuit common	


Remark: In the following paragraphs the terminals will be related to all the mounting types as in the following sample:

H/R-2a,E-J4/13.

---

\*  $-1V \leq V_{il} < 1V$  ;  $2V \leq V_{ih} < 30V$   
 Source sink capability - 2mA min.





# MBA-DBA/3UE

**NOT AVAILABLE YET**

**MBA-DBA/6UE**

## 5.4 Communication Port Connector

The serial communication is available via a 9 pins D connector (Jc) with the following pin assignment:

### RS232

Pin	Function
2	Receive
3	Transmit
5	Common

When using an IBM XT as an host, pins 4 and 5 should be connected together on the 25 pins D connector (computer side). When using an IBM AT as an host, pins 7 and 8 should be connected together on the 9 pins D connector (computer side).

### RS485

Pin	Function
5	Common
6,7	T/R -
8,9	T/R +

## **6. Installation procedures**

### **6.1 Mounting**

The DBA series dissipates its heat by natural convection except DBAF types which are fan cooled. For optimum dissipation the amplifiers have to be mounted with the fins in vertical position.

### **6.2 Wiring**

Proper wiring, grounding and shielding techniques are important in obtaining proper servo operation and performance. Incorrect wiring, grounding or shielding can cause erratic servo performance or even a complete lack of operation.

- a) Keep motor wires as far as possible from the signal level wiring (feedback signals, control signals, etc.).
- b) If additional inductors (chokes) are required, keep the wires between the amplifier and the chokes as short as possible.
- c) Minimize lead lengths as much as is practical. Although the amplifier is protected against long (inductive) supply wires it is recommended to keep the leads as short as possible.
- d) Use twisted and shielded wires for connecting all signals (command and feedback). Avoid running these leads in close proximity to power leads or other sources of EMI noise.
- e) Use a 4 wires twisted and shielded cable for the motor connection.
- f) Shield must be connected at one end only to avoid ground loops.
- g) All grounded components should be tied together at a single point (star connection). This point should then be tied with a single conductor to an earth ground point.
- h) After wiring is completed, carefully inspect all conditions to ensure tightness, good solder joint etc.

### 6.3 Load inductance

The total load inductance must be sufficient to keep the current ripple within the limits - 50% of the adjusted continuous current limit. The current ripple ( $I_r$ ) can be calculated by using the following equation:

$$I_r = \frac{0.5 \times V_s}{f \times L} \quad (\text{A})$$

$L$  - load inductance in mH.

$V_s$  - Voltage of the DC supply in Volts.

$f$  - Frequency in KHz.

If motor inductance does not exceed this value, 3 chokes should be added (to each motor phase) summing together the required inductance

$$L_{ch} = L - L_p$$

$L_{ch}$  - Choke inductance

$L_p$  - Total inductance between two phases (in Y connection it is the sum of two phases).

### 6.4 DC power supply

DC power supply can be at any voltage in the range defined within the technical specifications (chapter 3). However, if the power source to the power supply is the AC line (through a transformer), safety margins have to be considered to avoid activating the under/over voltage protection due to line variations and/or voltage drop under load.

The nominal DC bus voltage should be in the following range:

$$1.2V_{dcmin} < V_{dc} < 0.9V_{dcmax}$$

$V_{dcmin}$  - Minimum DC bus in the table of chapter 3


$V_{dcmax}$  - Maximum DC bus in the table of chapter 3

The transformer power should be calculated to have the capability to deliver power to the amplifier (including peak power), without significant voltage drops.



While driving high inertia loads, the power supply must be equipped with a shunt regulator, otherwise, the amplifier will be disabled whenever the capacitors are charged above the maximum voltage.

## 6.5 Wiring diagrams



### 6.5.1 Motor's windings



Minimum acceptance




Acceptable for most applications



Optimum wiring, minimum RFI

## 6.5.2 AC power wiring

### NON-ISOLATED AC SUPPLIES BY USING AUTOTRANSFORMER



#### Guide lines for connecting non-isolated AC supplies

##### Ground:

Control common  
Motor chassis  
Amplifier's heatsink

##### Do not ground:

Power common


(The power common is a hot point and any grounding will cause an input rectifier failure).

##### Caution:

- If source of motor command is grounded, use amplifier's differential input. Otherwise, ground loop is created.



# ISOLATED AC SUPPLIES



## Guide lines for connecting an Isolated amplifier with an isolating power transformer

### Ground:

DC power common


Control common

Motor chassis

Amplifier's heat sink.

### Caution:

- If source of motor command is grounded, use amplifier's differential input. Otherwise, ground loop is created.



### **Guide lines for connecting a non isolated amplifier with an isolating power transformer**

#### **Ground:**


DC power common  
 Motor chassis  
 Amplifier's heat sink

#### **Do not ground:**

Control common - It is internally connected to the power common. Grounding the control common will create a ground loop.

#### **Caution:**


- If source of motor command is grounded, use amplifier's differential input. Otherwise, ground loop is created.



CONNECTING MORE THAN ONE DBA


All rules about supply connections described in the previous pages are also valid for multi-DBA connection.

6.5.3 Hall sensors wiring



## 6.5.4 RS232 Communication wiring


# RS232 COMMUNICATION



### NOTE:


SHIELDING MUST BE CONNECTED AT COMPUTER END ONLY

### SYMBOLS:



### 6.5.5 RS485 Communication wiring


## RS 485 COMMUNICATION




#### NOTES:

1. SHIELDING MUST BE CONNECTED AT COMPUTER END ONLY
2. PIN No.1 TRANSMIT/RECEIVE CONTROL
3. PIN No.4 +5V

#### SYMBOLS:




# RS485 COMMUNICATION




**NOTES:**

1. SHIELDING MUST BE CONNECTED AT COMPUTER END ONLY.
2. PIN No.1 TRANSMIT/RECEIVE CONTROL
3. PIN No.4 +5V

**SYMBOLS:**




**6.5.6 Main encoder wiring**





### 6.5.7 Resolver wiring


## RESOLVER CONNECTION




#### NOTES:

1. PIN No 7 = +15V
2. PIN No 8 = -15V
3. PIN 9 AND THE METAL FRAME OF J2 ARE INTENALLY CONNECTED TO THE DCB COMMON. THE SHIELDINGS OF ALL THE PAIRS SHOULD BE CONNECTED EITHER TO J2 PIN 9 OR TO THE FRAME OF J2.


#### SYMBOLS:



### 6.5.8 Auxiliary encoder wiring



**6.5.9 Pulse/Direction signals wiring**



## **7. Start - Up Procedures**

### **7.1 Common procedures for all amplifiers types**

#### **7.1.1 Commutation signals format**

Select the position of DIP switch 1 on the upper board of the power stage according to the commutation signal format the motor has.

DS1 positions:	ON (down): 30°	OFF (up): 60°
----------------	----------------	---------------

For all Resolver versions it should be 60°.

#### **7.1.2 CFM function**

Select the position of DIP switch 2 on the upper board of the power stage according to the motor's rated current. If it is less than 20% of the amplifier's rated current select:

DS2 to ON (down)
------------------

Otherwise,

DS2 to OFF (up) - No CFM
--------------------------

#### **7.1.3 Abort logic**

Make sure that the Abort input is connected to a High (logic) voltage source.

### 7.1.4 Setting the auxiliary position input format

This step is valid only for those applications that need to use the auxiliary position input. You may skip this step if you do not use it.

#### When using an Optical encoder

Set DS 7 to OFF

When a the encoder has differential outputs:

Set DS 4 and 5 to OFF

Otherwise they should be ON.

#### When using Pulse and Direction signals

Set DS 7 to ON

### 7.1.5 Selecting the communication bus

Select the desired communication bus as follows:

For RS232: Set DS9 to OFF

For RS485: Set DS9 to ON

### 7.1.6 Preparing the automatic baud rate selection

The DCB baud rate will automatically match the host baud rate when DS1 is set to ON.

Set DS1 to ON

### 7.2 Setting the main optical encoder format

When a differential encoder is used:

Set DS 2,3,6 to OFF

Otherwise they should be ON.

### 7.3 Setting the R/D circuit

Set DS 2,3,6 to ON


The Resolver interface circuit consists of three basic blocks:

**R/D converter**

The R/D conversion is done by a variable resolution, monolithic converter type 2S82 of Analog Devices. It accepts two signals from the Resolver (sine and cos.) and converts them into binary position data bits. The resolution of the position bits is user selectable 10, 12, 14 and 16 (only for standard encoder resolution). In addition, the R/D creates a signal that is proportional to the Resolver velocity. This signal is being used as a velocity feedback.

**EPROM**

The EPROM creates "Hall" signals by mapping the position data bits accepted from R/D into suitable Hall signals to operate a specific brushless motor. In addition, the encoder index (marker) signal is also produced from the EPROM. The EPROM is designated as follows:



In the S (standard) version zero crossing of phases B C occurs at position address "0" of the Resolver.

**Oscillator**

Creates sinusoidal waveform signal to excite the primary of the Resolver.

**Oscillator Frequency/Amplitude Selection (R228,R233)**

The frequency ( $f_r$ ) and amplitude ( $V_r$ ) needed to excite the Resolver are taken from the Resolver data sheet.

Selecting the frequency:

$$R228 = 110/f_r \quad (\text{Kohm})$$

$$0.1\text{KHz} < f_r \text{ (KHz)} < 20\text{KHz}$$

Selecting the amplitude:

Pay attention that the RMS amplitude does not exceed  $7V_{rms}$  or that the peak-to-peak (ptp) value is within the range of  $2V \leq V_{r_{ptp}} \leq 20V$ . For  $V_r$  in peak-to-peak value:

$$R233 = 6/(V_r - 2) \quad (\text{Kohm})$$

For  $V_r$  in RMS value:

$$R233 = 6/(2.82V_r - 2) \quad (\text{Kohm})$$

Reference Voltage level to R/D (R192)

In order to adjust the reference voltage input level to  $2V_{rms}$ , select R192 as follows:

$$R192 = 50 \times (V_{r_{rms}} - 2) \quad (\text{Kohm})$$

For  $V_{r_{rms}} < 2V$ , install  $R192=100 \text{ ohm}$ .

Signal input level (R193,R194)

The R/D inputs ( $V_{in_{rms}}$ ) are adjusted to the sin/cos. Resolver outputs by:

$$\text{Resolver output} = V_{in_{rms}} = V_{r_{rms}} \times \text{Transformation ratio}$$

$$R193 = R194 = V_{in_{rms}} - 2 - R_{stator} \quad (\text{Kohm})$$

( $R_{stator}$  in Kohm).

**When  $V_{in_{rms}} < 2V$ , install  $R193=R194=100$  ohm.**

**The standard R/D converter will not operate for  $V_{in_{rms}} < 1.8V$ . Consult factory for OEM applications.**

Velocity Signal

The tracking converter technique generates an internal signal at the output of the integrator that is proportional to the rate of change of the input angle. This dc analog output (velocity signal) is buffered and represented at terminal H/R-12b,E-J3/23. **Max output voltage is  $\pm 8V$ .**

This velocity signal can be internally connected to the summing junction of the error amplifier by inserting R7 - see Appendix B for more details. However, the standard procedure does not require closing the velocity loop.

Select maximum actual velocity of the application and calculate the maximum tracking rate T of the Resolver as follows:

$$T = \text{rpm} \times Q / 120$$

T unit is rps: Resolver electrical revolution per second

Q - number of poles of Resolver ;

rpm - mechanical revolution per minute.

Selecting the Resolution

The resolution can be selected to be 10,12,14 or 16 bits by use of DIP switches 13 and 14. When selecting the resolution the rps limits should not be exceeded:



10 bit = 1040 rps  
 12 bit = 260 rps  
 14 bit = 65 rps  
 16 bit = 16.5rps

Resolution	DS13	DS14
10	ON	ON
12	ON	OFF
14	OFF	ON
16	OFF	OFF

Note:

- Each resolution change must be followed by new components selection procedure.
- When changing resolution under dynamic conditions, a period of uncertainty will exist before position and velocity data is valid.

Encoder resolution

In the STD mode (DS12 OFF), the encoder signals A,B are created by the EPLD and can have only the following basic resolutions (for 2 pole Resolver):

256 for 10 bits  
 1024 for 12 bits  
 4096 for 14 and 16 bits

When the Resolver is more than 2 poles, the resolution for one shaft rotation will be:

$$Er = Q \times S / 8$$

Q = number of Resolver poles ;  
 S = resolution of converter ( $2^{10}$ ,  $2^{12}$ , or  $2^{14}$ )

When different encoder resolution is needed the encoder signals are generated by the EPROM and the R/D resolution is no longer user selectable.

This option requires

- DS12 at ON
- Special EPROM which is programmed for this resolution.

HF Filter (R195, R196, C61, C62)

The function of the HF filter is to reduce the amount of noise present on the signal inputs to the 2S82, reaching the Phase Sensitive Detector and affecting the outputs. Values should be chosen so that

$$15\text{Kohm} < R195=R196 < 30\text{Kohm}$$

$$C61 = C62 = \frac{160 \times 10^3}{R195 \times fr} \quad (\text{pF})$$

fr = Reference frequency in KHz

R195 in Kohm

This filter gives an attenuation of 3 times at the input to the phase sensitive detector.

AC Coupling of Reference Input (C60)

Select C60 so that there is no significant phase shift at the reference frequency. That is,

$$C60 = \frac{10^6}{fr(\text{KHz}) \times Rx} \quad (\text{pF}) \quad Rx = \frac{100 \times R192}{100 + R192} \quad (\text{Kohm})$$

R192 in Kohm

If Rx yields less than 50K, install a value of Rx=50K in the C60 equation.

Maximum Tracking Rate (R201)

The VCO input resistor R201 sets the maximum tracking rate of the converter and hence the velocity scaling as at the maximum tracking rate, the velocity output will be 8V.

Decide on your required maximum tracking rate, "T" , in revolutions per second. Note that "T" must not exceed the specified maximum tracking rate or 1/16 of the reference frequency.

$$R201 = 5.92 \times 10^7 / T \times p \quad (\text{Kohm})$$

where p = bit per rev  
 = 1,024 for 10 bits resolution  
 = 4,096 for 12 bits  
 = 16,384 for 14 bits  
 = 65,536 for 16 bits

Closed Loop Bandwidth Selection (C67, C68, R200)

a. Choose the Closed Loop 3dB Bandwidth ( $f_{bw}$ ) required ensuring that

$$f_{ref} > 10 \times f_{bw}$$

Recommended bandwidth values:

250Hz for 3KHz

300Hz for 5KHz

500Hz for 10KHz

b. Select C67 so that

$$C67 = \frac{2.5 \times 10^9}{R201 \times f_{bw}^2} \quad (\text{pF})$$

with R201 in Kohm and  $f_{bw}$  in Hz as selected above.

c. C68 is given by

$$C68 = 40 \times C67 \quad (\text{pF})$$

d. R200 is given by

$$R200 = \frac{127 \times 10^7}{f_{bw} \times C68} \quad (\text{Kohm})$$

$f_{bw}$  in Hz, C68 in pF

R200 value should be at least three times R197.

Gain Scaling Resistor (R197)

R197 should be installed according the following table:

536Kohm for 10 bits resolution

130Kohm for 12 bits

33Kohm for 14 bits

8.2Kohm for 16 bits

## **8. Applying power - Adjustments**

**Important remarks:**

**A. If all the previous steps were accomplished you may now disconnect the motor leads, turn the power on and continue with the following adjustments.**

### **Step 1 - Applying Power**

Apply power and check for LED Vs of the DCB that should be "ON", indicating that the system supplies are present. The display should read: "F-OK". If you get another message, refer to the following table to find the cause of the problem. Turn the power off, clear the cause of the problem and re-power the unit.

Event	Display	Display after Recurring
DIP switch 1 - ON	BAUD	OK
Load is under cont. current limit	CLIM	C-OK
Battery Low	BATT	B-OK
Abort condition (hardware only)	ABRT	A-OK
Amplifier's power stage disabled*	AMPD	H-OK
-15V out of limits	-15V	F-OK
Under or Over Voltage	VOLT	F-OK
+15V out of limits	+15V	F-OK
Over Temperature	TEMP	F-OK
Commutation problem	CMMT	F-OK
Short condition at the power outputs	SHRT	F-OK

---

\* The AMPD message appears in two cases:

1. When MO (Motor Off) command is given.
2. Position error exceeds the allowed value.

## Step 2 - Establishing the communication

Press CR (carriage return) in the host several times until the DCB sends the message "Communication OK".

If you want to "lock" the baud rate in the DCB:

- Turn off the power and remove the amplifier from the rack if it is a rack version.
- Set DS1-OFF.

Now the baud rate you selected is stored in the SRAM.

It is possible to change DS1 at any time. However, the DCB will notice the change only upon power on or hardware reset.

## Step 3 - Checking the feedback elements

- Turn on the power.
- Rotate the motor shaft manually and interrogate the position with the instruction:

TP (CR)

The controller response should vary as the motor is turned. If this does not occur, check the feedback signals.

- When using the auxiliary encoder input, rotate the auxiliary encoder and interrogate the position with the instruction: PY.

The controller response should vary as the encoder is turned. If this does not occur, check the feedback signals. The DCB is counting quadrature pulses. This means that for encoders or resolvers the answer for a TP command will be 4 times the number of basic encoder pulses and for Pulse/Direction mode it will be twice the number of pulses.

## Step 4 - Adjusting the current limits

### Defining the amplifier type

- Define the maximum current of the amplifier by the instruction:

MCn

n - rated peak current of the amplifier in A as given in the table of chapter 3.

For example: n is 60 for DBAF-30/160

**Current limit adjustments**

- Define the continuous current limit by the instruction:

CLn.m           (n.m - current in A)

- Define the peak current limit by the instruction:

PLn.m           (n.m - current in A)

- Define the maximum peak current duration by the instruction:

PDn.m           (n.m - seconds)

**Step 5 - Latch mode of the protective functions**

All the protective functions activate internal inhibit. There are two modes of resetting the amplifier after the cause of the inhibit disappears:

**Self Restart: (LM0)**

The amplifier is inhibited only for the period that the inhibit cause is present.

**Latch (LM1)**

Each failure latches the Inhibit and the failure message on the display. For restart (after clearing the failure source), reset has to be performed by applying logic 0 at the reset input (H/R-17a,E-J3/21), or by turning the power off and on.

**For safety reason it is recommended to use the amplifier in the LATCH MODE - LM1**

**Step 6 - Connecting the Motor**

- Turn off the power.
- Connect the leads of the motor.
- Turn on the power.

For proper operation, the system must have negative feedback. If the motor remains in the same position and returns to the same position when you turn the motor shaft and let go, then the position feedback is negative as required. If the motor runs away you have positive feedback. To correct the feedback, just reverse the encoder leads.

## 9. Tables and Summaries

### 9.1 Display diagnostics

Each amplifier's fault is stored immediately in the DCB RAM. In addition to that, a Failure Message is displayed. Following are all the valid Display Messages:

Event	Display	Display after Recurring
DIP switch 1 - ON	BAUD	OK
Load is under cont. current limit	CLIM	C-OK
Battery Low	BATT	B-OK
Abort condition (hardware only)	ABRT	A-OK
Amplifier's power stage disabled*	AMPD	H-OK
-15V out of limits	-15V	F-OK
Under or Over Voltage	VOLT	F-OK
+15V out of limits	+15V	F-OK
Over Temperature	TEMP	F-OK
Commutation problem (for brushless drives only)	CMMT	F-OK
Short condition at the power outputs	SHRT	F-OK

---

\* The AMPD message appears in two cases:

1. When MO (Motor Off) command is given.
2. Position error exceeds the allowed value.



## 9.2 Summary of DIP switches

### Power stage board

#### (2 poles DIP switch)

DIP switch	OFF (UP)	ON (DOWN)
DS1	60° commutation signals format	30° commutation signals format
DS2	No CFM	Activate CFM

### Control stage board

#### (9 poles DIP switch)

DIP switch	ON	OFF
DS1	Auto-selection of Baud rate	Latch last value
DS2	Non-differential channel A	Diff. input of channel A
DS3	Non-differential channel B	Diff. input of channel B
DS4	Non-differential channel Ay	Diff. input of channel Ay
DS5	Non-differential channel By	Diff. input of channel By
DS6	Non-differential index	Diff. index
DS7	Pulse/Direction format	Encoder channels format
DS8	N/C	
DS9	RS485	RS232

#### 4 poles DIP switch (for Resolver)

Switch	OFF	ON
DS11	Tacho signal disconnected	Tacho signal connected to error amplifier.
DS12	Standard encoder resolution	Non-standard encoder resolution
DS13	14 bit resolution (DS14-ON) 16 bit resolution (DS14-OFF)	10 bit resolution (DS14-ON) 12 bit resolution (DS14-OFF)
DS14	12 bit resolution (DS13-ON) 16 bit resolution (DS13-OFF)	10 bit resolution (DS13-ON) 14 bit resolution (DS13-OFF)

## **Appendix A - Current loop response**

In most applications it is not necessary to adjust the current loop to achieve the optimum response. When there are extreme electrical parameters in the armature circuit (inductance and resistance) the standard components values of 0.01 $\mu$ F for C1 and 100Kohm for R4 may not yield with the optimum response. The current loop should be optimized as follows:

- Insert R7 (1K) to connect the tacho input to the error amplifier. The amplifier must not be configured into velocity mode. If the resolver option is used, make sure that DS11 is OFF.
- Apply power to the amplifier and send the command BA.
- Provide the tacho input H/R-12b,E-J3/23 with a bi-directional square wave current command (100-200Hz, +2.0V waveform is often employed).

- Monitor the load current either by a current probe or by the current monitor.

If the current response is not critically damped, use the following procedure:

- Short circuit C1 with a short jumper wire.
- Replace R4 with a decade resistance box. Initially set the box resistance at 10Kohm.
- Apply the square wave test signal to the amplifier input.
- Apply power, and while monitoring the load current, gradually increase the value of the box resistance until optimum response as depicted in Fig A-1 is achieved.
- Substitute the closest standard value discrete resistor for R4 and remove the decade resistance box.
- Remove the shorting jumper across C1, and again check the response using the square wave test signal.
- If the previous step does not yield satisfactory results, if unacceptable overshooting has been noted, substitute a larger value than 0.01 $\mu$ F; or, if the response is overdamped, substitute a smaller value than 0.01 $\mu$ F. Repetition of this procedure should yield an optimum choice for C1.




Fig. A-1

Typical current response waveforms

**Appendix B - Adding a velocity feedback**

**THIS PAGE IS BLANK**

## **Appendix C - Differential amplifier connection**

The differential amplifier is provided for your optional use. It can be used for buffering, inverting or elimination of common mode signals.

The differential amplifier inputs are available at terminals H/R-9b,E-J3/1, H/R-10b,E-J3/2. Terminal H/R-10b,E-J3/2 is the inverting input, terminal H/R-9b,E-J3/1 is the non-inverting input. The output is on terminal H/R-11b,E-J3/3. The differential amplifier can be internally connected to the summing junction by inserting R800.

The differential amplifier may be used as a buffer or as an eliminator of common mode signals. For a non-inverting buffer amplifier, connect the positive signal lead to terminal H/R-9b,E-J3/1 and the negative signal lead to terminal H/R-10b,E-J3/2, and connect terminal H/R-10b,E-J3/2 to the circuit common. For an inverting buffer amplifier, connect the positive signal lead to terminal H/R-10b,E-J3/2, the negative signal lead to terminal H/R-9b,E-J3/1, and connect terminal H/R-9b,E-J3/1 to the circuit common. The output of the differential amplifier is given by:

$$V_O = \frac{10xV_1}{10 + R3} \times \left( 1 + \frac{10}{R2} \right) - \frac{10xV_2}{R2}$$


$V_1$  - Input voltage of terminal H/R-9b,E-J3/1.


$V_2$  - Input voltage of terminal H/R-10b,E-J3/2.

$$V_{1max} \leq 10 + R3; \quad V_{2max} \leq 100/R2$$

**See schematic in chapter 4.**


# **DIMENSIONAL DRAWINGS**

**DBA1 - TOP VIEW**





**DBA1 - SIDE VIEW 1**






**DBA1 - SIDE VIEW 2**


**DBA2 - TOP VIEW**




**DBA2 - SIDE VIEW 1**




**DBA2 - SIDE VIEW 2**




# DBA RACK MOUNTING (3U/13T) - SIDE VIEW 1



## DBA RACK MOUNTING (3U/13T) - SIDE VIEW 2




# FRONT PANEL FOR DBA 3U/13T




**DBA RACK MOUNTING (3U/20T) - SIDE VIEW 1**






## DBA RACK MOUNTING (3U/20T) - SIDE VIEW 2



# FRONT PANEL FOR DBA 3U/20T

# ENCLOSURE FOR DBA



### Standard Sizes

	16T	20T	24T	36T	48T
X	82.3	102.7	123.0	184.0	245.0

NOTE:

ALL DIMENSIONS ARE IN mm.

For non-standard sizes:

$$X = 5.08 \times n + 1 \text{ mm}$$

**List of ELMO Service Centers**

**ISRAEL**

Elmo Motion Control LTD  
34 Segula ST.  
Petah-Tikva 49103  
Tel: (03)934-5059  
Fax: (03)934-5126

**U.S.A**

Elmo Motion Control INC.  
1200 Woodruff Road, Suite C-22,  
Greenville, SC 29607  
Tel: (803) 288-9316  
Fax: (803) 288-9318

**EUROPE**

Elmo Motion Control  
Stanserstr. 7  
CH-6362 Stansstad, Switzerland  
Tel: (041) 610775  
Fax: (041) 610778

=====

**AUSTRIA**

Kwapil  
POB 64  
A-1091 Wien  
Tel: (0222) 342597  
Fax: (0222) 311203

**BENELUX**

Eltromat B.V.  
Looierij 26  
4760 AB Zevenbergen  
The Netherlands  
Tel: (01680) 25925  
Telefax: (01680) 28485

**FINLAND**

OY Scandrive  
Elsankuja 2 K  
SF-02231 Espoo  
Tel: 358-0-8035044  
Fax: 358-0-8035055

**FRANCE**

A 2 V SA  
11-12 Rue Eugene Henaff,  
78190 Trappes,  
Tel: (1) 30620101  
Fax: (1) 30626204

**GERMANY**

IME GmbH  
Brugger Str. 8  
78628 Rottweil  
Tel: 0741/22091  
Fax: 0741/22060

**ITALY**

Servotecnica SRL  
Viale Lombardia 20  
20095 Cusano Milanino (MI)  
Tel: (02) 66401010  
Fax: (02) 66401020

**SWEDEN**

Aratron AB  
P.O.B 20087,  
Kratsbodavagen 50,  
S-16120 Bromma  
Tel: 8-981875  
Fax: 8-984281

**UNITED KINGDOM**

INMOCO Limited  
4 Brunel Close  
Drayton Fields  
Daventry NN11 5LE  
Tel: 0327/300320  
Fax: 0327/300319